





Sheen levels are shown for indication purpose only.

HI SHEEN FINISH

NEO GOLD FINISH

Royale Glitter

Low VOC as per international specifications,

absence of hazardous and toxic materials. **DIRECTIONS FOR USE**

Royale Shyne

FINISH VARIANTS

SOFT SHEEN FINISH

NEO SILVER FINISH

Royale Glitter

Royale Aspira



Apply 1 coat of Asian Paints TruCare interior wall primer and allow drying for 4 – 6 hours. Smoothen the surface with coats of Asian Paints Trucare Acrylic Wall Putty. Allow drying for 4 – 6 hours. Sand the surface with Sand Paper No. 180 and wipe clean. Apply another coat of Asian Paints TruCare interior primer and allow drying for 4 – 6 hours. Sand the surface with sand paper No. 320 or 400 and wipe clean. Thin 1 litre of Royale Luxury Emulsion with 400 – 500 ml of water. Apply 2 – 3 coats of Royale Luxury Emulsion with a 4 – 6 hour gap between each coat using a felt roller. For best results, use Asian Paints Royale Roller for application. For best results, use:

Unmatched stain resistance

Sand the surface with Sand Paper No. 180 to remove loose

particles or dirt and wipe clean.

ASIAN PAINTS SERVICES: 🚵 consultancy@home For Colour Consultancy at Home SMS 'CCH' to 56161. 🏚 home solutions For Professional Painting Service SMS 'PAINT' to 56161.

Asian Paints Limited, 6A, Shantinagar, Santacruz (East), Mumbai - 400055.

of Painting Tools wall primer For more information on painting and colour selection, ezycolour log on to www.asianpaints.com, or call us at: 1800-209-5678

Free sample. Not for retail sale.

Asian Paints Range TruCare interior